

BMS_DATA_ENGINE;[xes_InvalidItemID] VLink in line: <n>

Error Message	<i>BMS_DATA_ENGINE;[xes_InvalidItemID] VLink in line: <n></i>
Related Products	BMS Server 2.0
Description	The ItemID provided in the virtual link in the give line is invalid.
Causes	The provided ItemID cannot be found in the item tree.
Resolutions	Go to <i>Extensions / V-Link definitions</i> and use an existing ItemID in the mentioned line.