

# Backup/Recovery Voyager 5.0

- Install the whole software at the new PC
- Copy all workspaces from the old to the new PC (the installation directory is used at "C:\Program Files (x86)\NETxAutomation\").
  - Voyager 5.0:
    - Workspaces: C:\Program Files (x86)\NETxAutomation\Voyager.5.0.OPC\Workspaces
    - Libraries (if necessary): C:\Program Files (x86)\NETxAutomation\Voyager.5.0.OPC\Libraries
- Transfer softlock license:
  - Get removal code from the license manager at the old PC
  - Start license manager at the new PC
  - Send removal code and new license request to NETxAutomation
  - Install license at the new PC